

## Cleaning tablets 2 in 1

Tablets for cleaning and protecting JURA fully automatic coffee machines

### Mode of action

Alkaline cleaning tablets especially developed for Jura fully automatic coffee machines for thorough removal of coffee fat and deposits. The formulation is tailored to use in Jura fully automatic coffee machines and ensures effective while gentle cleaning, thereby extending the life of your coffee machine. They can also be used for thermos flasks and other containers/devices where deposits must be removed. Please see that the tablets must be dissolved with water of at least 90 °C.

#### Properties

Tablet, cylindrical, hemisphere  
Colour: lower part: white/upper part: blue  
Neutral odour  
Height: < 14.7 mm  
Diameter: 16.5 mm  
Weight: 3.5 g  
Soluble in water.  
pH 10-11 (3.5g/0.25 ml; 20 °C, 12 °dH)  
Dissolution time (0.25 l/90 °C): < 10 min

#### Ingredients

(according to regulation (EC) No 648/2004)  
PENTASODIUM TRIPHOSPHATE  
SODIUM CARBONATE PEROXIDE  
SODIUM CITRATE  
SODIUM ADIPATE  
SODIUM CARBONATE  
SODIUM LAURYL SULFATE  
POLYMER  
MAGNESIUM STEARATE  
BLUE COLORANT  
For more information on the ingredients  
please click [here](#).

#### Instructions for use

1. Place a sufficiently large receptacle (ca. 0.5 litres) under the height-adjustable coffee spout.
2. Start the cleaning operation as described in the instructions for use of your machine.
3. Drop a cleaning tablet inside the filler funnel for pre-ground coffee.
4. The rest of the procedure is described in the instructions for use of your machine.

### Toxicological and ecological information

The product is classified as irritant, i. e., short, frequently or prolonged contact with skin may cause inflammations. The operation of public sewage treatments plants is not affected even if added in larger amounts. The product complies with the biodegradability criteria as laid down in Regulation (EC) No.648/2004 on detergents.

### Handling, storage and disposal considerations

Keep container tightly closed, protect against humidity, water and heat.  
Waste code product: 20 01 29  
Residues of the product can be disposed of in the normal drainage system.

### Hazards identification

Warning

H319: Causes serious eye irritation.

P102: Keep out of reach of children.

P264: Wash hands thoroughly after handling.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P337+P313: If eye irritation persists: Get medical advice/attention.

### First aid measures

In case of accident or if you feel unwell, seek medical advice immediately (show directions for use or safety data sheet if possible). Change **contaminated, saturated clothing** immediately.

If the tablet, tablet dust or the cleaning solution get into contact with the **eyes**, flush immediately with plenty of flowing water for 10 to 15 minutes holding eyelids apart and consult an ophthalmologist.

If the tablet, tablet dust or the cleaning solution is **swallowed**, rinse the mouth immediately and drink plenty of water. Do not induce vomiting. Seek medical advice if you feel unwell.

If the cleaning solution gets into contact with the **skin**, wash immediately with plenty of water.

### Packing units

Folding box of 2 tablets in a blister, folding box of 6 tablets in a blister, jar of 25 tablets, jar of 100 tablets  
Art. No. 58710, 59633, 62535, 62715, 64308, 64488, 68009, 69532, 70698

**JURA Elektroapparate AG**  
Kaffeeweltstraße 10  
CH-4626 Niederbuchsiten  
Tel.: +41 (0) 62 389 81 81  
[www.jura.com](http://www.jura.com)

**JURA Elektrogeräte Vertriebs-GmbH**  
Postfach 99 01 44  
D-90268 Nürnberg  
Tel.: 0180 3 523 333  
[www.de.jura.com](http://www.de.jura.com)

**JURA Gastro Vertriebs-GmbH**  
An der Zugspitze 1  
D-82491 Grainau  
Tel.: +49 (0) 8821 966 73-0  
[www.juragastroworld.de](http://www.juragastroworld.de)